



Unisoc Confidential For hiar

# Camera Optical Zoom Calibration Specification Introduction

Issue	V1.2
Date	2021-02-09

**Copyright © UNISOC (Shanghai) Technologies Co., Ltd. All rights reserved.**

All data and information contained in or disclosed by this document is confidential and proprietary information of UNISOC (Shanghai) Technologies Co., Ltd. (hereafter referred as UNISOC) and all rights therein are expressly reserved. This document is provided for reference purpose, no license (express or implied, by estoppel or otherwise) to any intellectual property rights is granted by this document, and no express and implied warranties, including but without limitation, the implied warranties of fitness for any particular purpose, and non-infringement, as well as any performance. By accepting this material, the recipient agrees that the material and the information contained therein is to be held in confidence and in trust and will not be used, copied, reproduced in whole or in part, nor its contents revealed in any manner to others without the express written permission of UNISOC. UNISOC may make any changes at any time without prior notice. Although every reasonable effort is made to present current and accurate information, UNISOC makes no guarantees of any kind with respect to the matters addressed in this document. In no event shall UNISOC be responsible or liable, directly or indirectly, for any damage or loss caused or alleged to be caused by or in connection with the use of or reliance on any such content.

Please refer to the UNISOC Documents in the UNISOC Deliverables for the use of the Deliverables. Any loss caused by the modification, customization or use of the UNISOC Deliverables in violation of the instructions in the UNISOC Documents shall be undertaken by those who conduct so. The performance indicators, test results and parameters in the UNISOC Deliverables are all obtained in the internal development and test system of UNISOC and are only for the reference. Before using UNISOC Deliverables commercially or conducting mass production of the Deliverables, comprehensive testing and debugging in combination with its own software and hardware test environment are pre-requisite.

Unisoc Confidential For hiar

**UNISOC (Shanghai) Technologies Co., Ltd.**



# About This Document

## Purpose




This document describes the calibration environment of camera optical zoom and calibration operations.

## Intended Audience

This document is intended primarily for the customers and UNISOC testers.

## Symbol Conventions

The symbols that may be found in this guide are defined in the following table.

Symbol	Description
 <b>NOTE</b>	Calls attention to important information, best practices and tips. NOTE is used to address information not related to personal injury, equipment damage, and environment deterioration.
 <b>CAUTION</b>	Calls attention to error-prone operations. CAUTION is used to address information not related to personal injury, equipment damage, and environment deterioration.
 <b>WARNING</b>	Calls attention to irreversible operations. WARNING is used to address information not related to personal injury and environment deterioration.

## Acronyms and Abbreviations

Acronym and Abbreviation	Full Name
T	Tele lens
W	Wide lens
SW	Super Wide
AF	Auto Focus

## Change History

Issue	Date	Description
V1.0	2019-09-05	The first official release.
V1.1	2020-01-03	Adjust the distance of the calibration.
V1.2	2021-02-09	Translate the Chinese into English.

## Keywords

Optical Zoom, Calibration.

Unisoc Confidential For hiar

# Contents

---

1 Optical Zoom Calibration Introduction.....	1
2 Optical Zoom Calibration .....	2
2.1 Calibration Environment .....	2
2.2 Calibration Process .....	3
2.3 Redefine Calibration Environment .....	5
3 Calibration Interface Function .....	6
3.1 Interface Function Description .....	6
3.2 Precautions .....	7
4 OTP Format Description .....	8

Unisoc Confidential For hiar

# List of Figures

<b>Figure 2-1</b> Size distribution of board .....	2
<b>Figure 2-2</b> Diagram of the board brightness .....	3
<b>Figure 2-3</b> Placement of the calibration board and the mobile phone .....	4
<b>Figure 2-4</b> Images of the calibration board .....	4
<b>Figure 2-5</b> Redefining the calibration environment .....	5
<b>Figure 3-1</b> input_parameters_values.txt configuration .....	7

Unisoc Confidential For hiar

## List of Tables

---

<b>Table 3-1</b> Interface function parameter description for module manufacturers .....	6
<b>Table 3-2</b> Interface function parameter description for mobile phone manufacturers .....	6
<b>Table 3-3</b> Sensor pixel arrangement for different Bayer Pattern values.....	7

Unisoc Confidential For hiar

# 1 Optical Zoom Calibration Introduction

---

Optical zoom calibration can measure the offset between two lenses with different focal lengths. It is used to reduce the image dislocation when the camera is switched in the process of optical zoom, to make the image switching smoother. Camera lens switching types are mainly divided into:

- Tele lens (T) switches to Wide lens (W).
- Wide lens (W) switches to Super Wide lens (SW)

This document takes SW to W as an example to introduce the optical zoom calibration.

## NOTE

To calibrate T lens switches to W lens, please change W to T and SW to W in the following content.

Unisoc Confidential For hiar




# 2 Optical Zoom Calibration

## 2.1 Calibration Environment

The elements of the optical zoom calibration environment include calibration board, the light source and the brightness of captured images.

- The board used for zoom calibration is as shown in [Figure 2-1](#). The dimension of the chessboard is 432mm × 288mm with symmetrical blanks around, where the height of the upper and the lower blanks is 46mm (± 0.5mm), and the width of the left and the right blanks is 34mm (± 0.5mm). The side length of each grid in the chessboard is 36mm (± 0.1mm). The dimension of the entire board is 500mm × 380mm.


**Figure 2-1** Size distribution of board



- The requirements for the light source are as follows.
  - Use a standard light source to illuminate the board. D65 light source with a color temperature of 6500K is recommended.
  - The light intensity ranges from 400Lux to 800Lux, and 400Lux is recommended.
  - The light source can be reflective or rear projection. The reflective light source should not cause glare on the image.

- The light irradiation should be well distributed. For the brightness of the captured image, the average gray value is required to be  $40 \pm 5$  (0 - 255). For reference, the average gray value of the white block in the green box is  $70 \pm 5$ . The size and the location of the area are as shown in the green box in [Figure 2-2](#). *This requirement only applies to module manufacturers.*

**Figure 2-2** Diagram of the board brightness




## 2.2 Calibration Process

The calibration steps are as follow.

- Step 1** Turn on the mobile phone camera, keep the direction of L4 of the mobile phone and the L2 of the board consistent and parallel, and the plane of the calibration board is parallel to that of the mobile phone. The placement of the calibration board and the mobile phone is shown in [Figure 2-3](#).

**Figure 2-3** Placement of the calibration board and the mobile phone




**Step 2** Keep the mobile phone camera 40cm ( $\pm 1$ cm) away from the calibration board, and this distance is fixed.

**Step 3** Capture two images as shown in **Figure 2-4** by the W lens and the SW lens. W image is on the left and SW image is on the right.

**Step 4** Call the calibration function as shown in **3.1 Interface Function Description** to calculate the calibration result of images.

**Figure 2-4** Images of the calibration board



#### NOTE

When a module with Auto Focus (AF) function, auto focus is required.


----End

## 2.3 Redefine Calibration Environment

In the production, the optical zoom calibration environment needs to be redefined, and the steps are as follow.

**Step 1** Fix the calibration board on the bracket as shown in [Figure 2-5](#), and fix the bracket to the platform. Adjust the angle of the platform to the horizontal direction to be about  $90^\circ (\pm 5\%)$ .

**Figure 2-5** Redefining the calibration environment



**Step 2** Fix the module vertically on another bracket on the platform away from the first bracket 40cm ( $\pm 1$ cm), and the bracket can move up, down, left and right.

**Step 3** Adjust the distance between the two brackets, and adjust the up, down, left to make the image display similar to [Figure 2-4](#), and then fix each component.

----End

# 3 Calibration Interface Function

## 3.1 Interface Function Description

Call corresponding function for calibration.

- The function for module manufacturer is as follows.

```
int WT_Calibration_VerificationRaw(const unsigned short* pLeftImage, const unsigned short* pRightImage,  
INPUT_WT_PARAM_DATA_T stInputParam, WT_OTP_DATA_T* pOutOTP, int swVCM, int wVCM)
```

Description of the interface function parameters are shown in [Table 3-1](#).

**Table 3-1** Interface function parameter description for module manufacturers

Parameter	Description
pLeftImage	the storage path of the image captured by W lens
pRightImage	the storage path of the image captured by SW lens
stInputParam	input the parameters
pOutOTP	output the OTP parameters
swVCM, wVCM	VCM value corresponding to the W lens and SW lens when capture the image

- The function for mobile phone manufacturer is as follows.

```
int WT_Calibration_VerificationYUV(const unsigned char* filename_left, const char* filename_right,  
INPUT_WT_PARAM_DATA_T stInputParam, WT_OTP_DATA_T* pOutOTP, int swVCM, int wVCM)
```

Description of the interface function parameters are shown in [Table 3-2](#).

**Table 3-2** Interface function parameter description for mobile phone manufacturers

Parameter	Description
filename_left	the storage path of the image captured by W lens
filename_right	the storage path of the image captured by SW lens
stInputParam	input the parameters
pOutOTP	output the OTP parameters
swVCM, wVCM	VCM value corresponding to the W lens and SW lens when capture the image

## 3.2 Precautions

- Define the left image as a W image and the right image as a SW image. The view angle of the SW image is larger than that of the T image, which cannot be reversed. Both images are stored in the same path.
- The calibration of module manufacturers needs to be carried out in Raw10 format, and the resolution of the primary and secondary lenses should be modified according to the specific sensor.
- The calibration of mobile phone manufacturers needs to be carried out in YUV (NV21) format.
- When the module manufacturers carry out the calibration, the Bayer Pattern setting of the image should correspond to the proper sensor pixel arrangement. The sensor pixel arrangement for different Bayer Pattern value is shown in [Table 3-3](#).

**Table 3-3** Sensor pixel arrangement for different Bayer Pattern values

Value	Sensor Pixel Arrangement
0	RGGB
1	GRBG
2	GBRG
3	BGGR

- The setting of input\_parameters\_values.txt is shown in [Figure 3-1](#). The parameter in the last row of the figure is the optical magnification, which needs to be configured according to the specific project.

**Figure 3-1** input\_parameters\_values.txt configuration

```

1 0, 24.000000
2 1, 0.300000
3 2, 0.300000
4 3, 10.000000
5 4, 10.000000
6 5, 10.000000
7 6, 1.500000
8 7, 1.500000
9 8, 1.500000
10 9, 20.000000
11 10, 0.500000
12 11, 0.500000
13 12, 0.500000
14 13, 0.500000
15 14, 0.600000
16 15, 0.600000
17 16, 0.300000
18 17, 0.300000
19 18, 10.000000
20 19, 10.000000
21 20, 0.000000
22 21, 1.000000
23 22, 1.0000
24 23, 1.00
25 24, 1.0
26 25, -2
27 26, 90
28 27, 50
29 28, 4.5000
30 29, 0.5
31 30, 3
32 31, 2.1
33

```

optical magnification

# 4

## OTP Format Description

---

If the calibration function returns **0** or the mobile phone interface displays **Pass**, it indicates the calibration is successful, and 118 integer data will be generated and stored in a .bin file.

Unisoc Confidential For hiar